

## Mounting Threads for PilotAware FX

<u>M5</u>



**▲ Notice...Please read before applying.** 

**M5** 



This template is a copy of the bottom face of FX. Please take careful consideration of the mounting holes and the side of the face you intend to mount FX on.

This is particularly important when using the 1/4 inch hole.



## Hole size quide.

M5 (5.3mm Drill Bit)

1/4 Inch (6.5mm Drill Bit)





<sup>1</sup>/<sub>4</sub> Inch